Configuring the PEPWave Modem for SmartScale

You will need:

- Flash Light
- An Activated 2FF Mini-SIM Card
- The name of the APN for the cell service you will be using (some cell carriers don't require this)

Ensure SmartScale is turned off

Open the Electronics Box



Locate the Modem



Insert the 2FF Mini-SIM Card



Insert the SIM card into slot A, in the orientation shown. Press it firmly until the card "clicks" into place.

The slot for the SIM card is located on the side of the modem where the antennas connect.



Apply Power Then Wait 3~4 Minutes

This will allow the modem enough time to start and initialize the Internet connection

After 3~4 Minutes, You Should See the Modem's Wi-Fi Network

New PEPWave Network Name will be something like:

SMARTSCALE____

Connect to this network using the password:

smartscale

Open a Web Browser and Go To http://192.168.1.1

If that page doesn't load, try: <u>http://192.168.50.1</u> If that page doesn't load, try: <u>http://192.168.2.1</u>

Broadband Possibilities		Web Admin
	Login Username: admin Password: CARbon123! Login	

For the username enter: admin For the password enter: CARbon1! or CARbon123! (for newer feeder) Then click "Login"

Under Dashboard, confirm Connection

PEPWAVE	Dashboard Network Advanced AP System Status	Apply Change
	WAN Connection Status Priority 1 (Highest)	Ċ
	Connected	Details
	Priority 2 D desired (Priority 2) connections here	
	Disabled Drai desired (Disabled) connections here	
	LAN Interface	
	Router IP Address: 192.168.1.1 WI-FI AP	ON Details
	SMARTFEED_165to1	
Logout	Device Information Model: Pepwave MAX BR1 M ni Firmware: 7.1.0 build 2860 Uptime: 0 days 0 hours 10 minutes CPU Load: 12 b Throughput: \$ 0.0 kbps \$ 0.0 kbp.	
	Additional WAN option is available for activat on, please click <u>here</u> for more information	
	Copyright © Pepwave. All rights reserved.	

Make note if the connection says anything besides "Connected"



Contact C-Lock

Call C-Lock +1-605-791-5657 to confirm everything is working correctly.